




**manual  
wall adjust  
KYNETT**

# KYNETT

**Pay attention! Always mount the wall adjust on a solid wall!**



Fix the wall adjust with the screws and plugs supplied.



# KYNETT

**Pay attention! Always mount the wall adjust on a solid wall!**

Depending on your wall construction place the fixings horizontal or vertically.



# KYNETT

The lower end of the wall adjust is ideally placed approximately **20-40 cm** from the floor.


The distance between the mounting holes of the fixings has to be **141 cm**.



# KYNETT

**Pay attention! Always mount the wall adjust on a solid wall!**

Once the fixings are attached to the wall, the rail can be mounted on the fixings.



# KYNETT

**Pay attention! Always mount the wall adjust on a solid wall!**

To adjust the height of the bracket loosen the knob, pull the knob, slide the bracket, click on the correct height and tighten the knob again.



# KYNETT

## **Pay attention!**

Always make sure you click the Kynett ONE securely into the bracket. You should hear a distinct click twice (top and bottom).

